



FAIRVIEW™

DEFINING ARCHITECTURE SINCE 1963

TECHNICAL INFORMATION

STRYÜM®

NON-COMBUSTIBLE ALUMINIUM FAÇADE / MANUFACTURED BY FAIRVIEW

CONTENTS

1. ABOUT THIS GUIDE	4	8. SHADOW VERTICAL	
2. INTRODUCTION		8.1 Installation Guide	12
2.1 About Stryüm	4	8.2 General Details	19
2.2 Key Features	5	9. SHADOW HORIZONTAL	6
3. PANEL SPECIFICATIONS	6	9.1 Installation Guide	40
4. COATING SPECIFICATIONS		9.2 General Details	47
4.1 Typical Coating Type	8	10. SEAM VERTICAL	
5. COATING DATA		10.1 Installation Guide	65
5.1 Powdercoat/Woodgrain Data	9	10.2 General Details	76
5.2 Anodised Data	9	11. STEP HORIZONTAL	
6. PERFORMANCE	15	11.1 Installation Guide	94
6.1 Fire	10	11.2 General Details	103
6.2 Average Expansion	10	12. FABRICATION DETAIL	
7. INSTALLATION DETAIL		12.1 Fabrication Considerations	118
7.1 Installation Considerations	11	13. WARRANTY	
7.2 Accessories	11	13.1 Important Warranty Information	118
		14. MISCELLANEOUS	24 - 30
		14.1 Manufacturing Quality	119
		14.2 Report Register	120

DISCLAIMER

The information contained in this publication and otherwise supplied to users of Genesis products is based on Fairview's general experience, best knowledge and belief. However, due to factors which fall beyond Fairviews's knowledge and control, which can affect the use of the products, no warranty is given, express or implied with respect to fitness for particular purpose or otherwise.

It is the responsibility of the architect, designer and various engineering parties to ensure that the details in this Installation Manual are appropriate for the intended application.

Fairview reserves the right to alter specifications at any time and without notice. Products are subject to natural variation as part of the manufacturing process, colours and textures may vary according to light and weather conditions. Due to this and limitations of the printing accuracy, colours in this brochure may vary. In case of doubt, please contact your local Fairview representative.

1. ABOUT THIS GUIDE

This manual has been developed to inform fabricators and contractors with an effective installation resource when working with Fairview's express installation cladding system, Stryüm.

The guide will provide easy to follow technical information. As uncontrollable conditions of the job scope alter, this guide is a comprehensive resource for users/installers. Fairview recommends seeking the advice of a professional prior to installation.

The information and recommendations contained herein are believed to be correct at time of publishing 05/12/2022. Fairview reserves the right to revise the contents of this manual.

2. INTRODUCTION

2.1 ABOUT STRYÜM

- Contemporary appearance, striking design
- Premium Product: Made in Australia, superior quality
- Solid Aluminium - deemed non-combustible, certified to AS530.1 and AS1530.3
- Easy installation
- Concealed fixing method
- Ventilated rainscreen facade system, including comprehensive range of trims and accessories
- Limitless colours including textured woodgrain and authentic anodised finishes



2.2 KEY FEATURES

PRODUCT DNA

Solid Aluminium

FINISH

Unlimited Powdercoat finishes, innovative woodgrain finishes and authentic anodised finishes.

APPLICATION

Type A, B, and C constructions where non-combustible materials are required such as mixed-use developments, residential construction, and large-scale government infrastructure projects like hospitals.

FINISH

Unlimited Powdercoat finishes, innovative woodgrain finishes and authentic anodised finishes.


WARRANTY

15-year warranty, subject to standard terms and conditions.



3. PANEL SPECIFICATION

SHADOW 160 - SH160




Thickness: 1.8mm

Weight: 6.9kg/m²

Length: 6.5m

Effective Cover: 160mm per panel

SHADOW 200 - SH200




Thickness: 2.5mm

Weight: 8.82kg/m²

Length: 6.5m

Effective Cover: 200mm per panel

SHADOW 300 - SH300




Thickness: 3.5mm

Weight: 11.29kg/m²

Length: 6.5m

Effective Cover: 300mm per panel

SHADOW 90/90 - SH90/90 (NEW)




Thickness: 2mm

Weight: 8.11kg/m²

Length: 6.5m

Effective Cover: 186.1mm per panel

SHADOW 170/95 - SH170/95/95 (NEW)




Thickness: 3mm

Weight: 10.94kg/m²

Length: 6.5m

Effective Cover: 271.1mm per panel

SEAM 260 - SE260




Thickness: 2.8mm

Weight: 11.07kg/m²

Length: 6.5m

Effective Cover: 260mm per panel

SEAM 130/130 - SE130/130 (NEW)




Thickness: 2.8mm

Weight: 12.69kg/m²

Length: 6.5m

Effective Cover: 260mm per panel

STEP 250 - ST250



Thickness: 2.8mm

Weight: 9.37kg/m²

Length: 6.5m

Effective Cover: 250mm per panel



4. COATING SPECIFICATIONS

POWDER COAT

Stryüm is available in the commercial Interpon and Dulux range of powder coat finishes. These commercial finishes have been tested to AAMA2604 and have been designed specifically for architectural applications. They are super durable thermosetting polyester powders ideal for use in mild, severe and tropical exterior conditions.

For increased warranties, AAMA2605 powder coat finishes are also available upon request. These finishes consist of ultra-durable fluoropolymer powder coat finishes. A virtually unlimited range of custom colours is available in powder coat, please speak to the Fairview team.

ANODISED

The Stryüm profiles are subjected to the anodising process and are supplied with an authentic anodised finish, there are many colour options to choose from.

Unlike a powder coat finish, anodising is not a coating, it is an alteration of the physical properties of the aluminium. This means the material has much better durability than a powder coat finish: authentic anodised finishes are the most durable type of finish available.

The Stryüm panels use an authentic anodised finish, which involves passing the raw material through an electrochemical process. This process highlights the natural variation of the aluminium, showcasing the natural lustres of the metal. As a result, anodising creates a vibrant, dynamic finish that morphs from one colour to the next when viewed from varying angles, and at different times throughout the day.

This natural variation is one of the design benefits of using Anodised aluminium, and the final appearance will not have the same ultra-consistent appearance as other finishes such as powder coating.

As anodising is a natural process there is a large potential for slight colour variation within the material, and when compared to the approved sample. However, this variation has always been part of the allure of anodising and will create a truly unique façade.

WOODGRAIN

Stryüm uses an innovative woodgrain technology known as powder on powder, or Interpon ezy HD2, the market leader in durability.

It has a raised grain, increasing the realism of the profile.

Dual powder is a process where a base layer of powder coat is applied, however is only partially cured.

This profile is then coated with a second layer of powder coat which forms the woodgrain pattern.

These two layers are then cured together to form a single layer, with a real grain texture. The final woodgrain finish is extremely durable, and it outperforms some other alternative woodgrain coating techniques.

The Stryüm woodgrain utilises the Interpon D2525 powders, and as such is treated as the same material.

Custom woodgrain finishes are available at request, please contact the Fairview team

5. COATING DATA

5.1 POWER COAT/ WOODGRAIN DATA

INTERPON D2525 AAMA2604 RESULTS		
TEST	RESULT	TEST REQUIREMENT
2450	2250	2150
2150	1950	1900
1950	1800	1700
1800	1650	1600
1700	1550	1450
1600	1400	1350
1550	1300	1200
1450	1200	1150
1350	1150	1050
1300	1100	1000
1200	1000	950
1150	950	NA
1100	950	NA

5.2 ANODISED DATA

All anodised finishes are supplied in accordance with AS1231 2000 Aluminium and Aluminium Alloys – Anodic Oxidisation Coatings.

6. PERFORMANCE

6.1 FIRE

In today's architecture the technical details are as important as the overall appearance of the project specification. Architects are seeking products that tick the box for sustainability, moisture control and fire performance.

The demand for specification and deemed non-combustible facades have fast become the industry norm.

As a solid aluminium pre-finished panel, Stryüm has been tested to AS1530.1* and AS1530.3. Powder coat and woodgrain finishes are compliant to the 2019 NCC under clause C1.9e (v).

Stryüm is a safe preferred choice where deemed non-combustible cladding must be specified for use, applications such as hospitals, schools and high-rise buildings.

POWDER COAT & WOODGRAIN FINISHES			
TEST STANDARD		RESULT	
AS1530.1		DEEMED NON-COMBUSTIBLE	
AS1530.3	PASS	Ignitability Index	11
	PASS	Heat Evolved	0
	PASS	Spread of Flame	0
	PASS	Smoke Developed	3
Compliance with C1.9E(v)		DEEMED NON-COMBUSTIBLE	

*AS1530.1 testing for Woodgrain Finish to be completed.

6.2 AVERAGE EXPANSION

MATERIAL	MATERIAL	ELONGATION PER 1000MM T =50°C
Stryüm	23.4	1.17

When installing Stryüm please leave the following clearance at each end of a length to allow for unhindered expansion and contraction.

LENGTH	CLEARANCE
≤ 4000mm	5mm
> 4000mm	10mm

The proprietary Stryüm S Batten is designed to sustain expansion of Stryüm in an 80°C temperature change, whilst allowing for a direct fix to the substrate.

If the Stryüm S Batten is not used, allowance must be made for thermal expansion in the form of oversized holes, with special attention paid in the installation of the material to ensure the screws are not overtightened.

7. INSTALLATION DETAIL

7.1 INSTALLATION CONSIDERATIONS

- As minor colour variation can occur between production lots, it is recommended the total material requirements for a project are placed in one order to ensure colour consistency.
- Where aluminium materials meet dissimilar metals, a proper insulator or caulking tape should be applied to insulate between dissimilar materials to avoid corrosive and electrolytic action.
- Please ensure Stryüm is used as part of a compliant wall system, with all components complying with the Deemed-to-Satisfy provisions of the relevant NCC or approved as part of a performance solution.
- Refer to the Stryüm Trims Guide and Vitrafix Accessory Brochure for a comprehensive range of compliant trims and accessories.
- When Stryüm panels are delivered to site, approximately 50mm of panel will need to be trimmed from both ends due to the production process. When ordering site specific sizes, please ensure you have allowed for 100mm – 150mm of wastage on each panel. Please ensure that both ends have been trimmed prior to installation, as this is vital to ensuring the panels will clip together fully.
- Stryüm panels will be installed with uncoated cut edges. Aluminium is extremely resistant to corrosion and within minutes of cutting the panel, a thin oxide layer will have formed over the cut edge, preventing any further corrosion.
- If installed as per the installation requirements, these edges are adequately drained and ventilated to prevent sitting in pooled water. If the panels are installed incorrectly so that they are subject to pooled water, this may eventually break down the oxide layer and allow for corrosion.
- When installing Stryüm, ensure that the panel has fully locked together before screwing it off. In the Stryüm shadow profiles, a 14mm packer can be inserted in the shadow line to ensure a complete connection. With the Seam and Step profiles, please tap the join using a soft faced hammer to ensure complete connection, taking care not to damage the finish.
- Due to the interlocking nature of the Stryüm, it is critical that special attention is paid to installing the S Batten substructure correctly. It must provide a flat surface for the cladding to be installed on, as any inconsistencies in the substructure may affect the visual appearance of the cladding.
- Movement in the building structure must be accounted for, and allowances included in fixing calculations accordingly.
- Stryüm, or the S Batten substrate, cannot be installed across:
 - Building movement or control joints,
 - Dissimilar substrates.
- Stryüm panels must not be fixed to a rigid substrate other than the S Battens.
- Stryüm panels must not be fixed in such a way to prevent movement, including direct fixing panels to flashing, or controlling any movement in the interlocking joints.
- Stryüm S Battens are to be installed perpendicular to the orientation of the cladding panels.
- A minimum cavity depth of 35mm is required.
- Deflection of the Stryüm panels must not exceed span/90.
- Ensure all cut edges have been coated with a suitable sealant.
- For Vertical installation of the Shadow and Seam profiles, Perforated S Battens should be used to promote airflow within the wall cavity and prevent moisture build up.
- For vertical installation of the Shadow and Seam profiles, ensure the orientation of the horizontal S Battens follows the drawing detail.

TRIMS & ACCESSORIES

All standard components are available from Fairview. Please visit Stryüm Trims Guide for further information.




8. SHADOW VERTICAL

8.1 INSTALLATION GUIDE

SHADOW VERTICAL – INSTALLATION GUIDE

Please ensure you review the complete Stryüm Shadow Vertical details on pages 18-37 to ensure you order all the required trims, the following step by step is a guide only

STEP 1 – WATERPROOF MEMBRANE




As Stryüm is a rainscreen façade, a weathertight membrane must be installed over the supporting wall. This membrane needs to meet the project specific requirements for weathertightness and be installed as per manufacturers guidelines. All penetrations through the membrane must be sealed.


ITEMS ON THIS PAGE			
CODE	DESCRIPTION	LENGTH	SUPPLIED BY FAIRVIEW
N/A	Waterproof Membrane	N/A	•
	Please contact Fairview		

*Proclima Extasana Wall Membrane was used as part of Stryüm AS4284 testing and is recommended for most applications, however project specific requirements need to be considered before selecting the appropriate membrane.

STEP 2 – SUBSTRATE



Use Stryüm Perforated S Batten as the top most batten.



*Take note of the S Batten orientation



Packers for a plumb substrate and ventilation need to be installed as required prior to the installation of the Stryüm S Batten.


Install Stryüm S Batten substrate horizontally. The substrate needs to be level to ensure the cladding is flat once installed. Any imperfections in this substrate will be highlighted once the panels are installed.

Stryüm S Battens are installed at maximum 600mm centres. Project specific requirements may dictate shorter span lengths. Use Perforated S Batten as the top batten.

ITEMS ON THIS PAGE

CODE	DESCRIPTION	LENGTH	SUPPLIED BY FAIRVIEW
TRM0901	35mm Stryüm Perforated S Batten	6.5m	•
TRM0903	35mm Stryüm S Batten Perforated	6.5m	•


STEP 3 – HORIZONTAL TRIMS



Install the horizontal trims for the cladding, at the top and bottom of the cladding section, above and below any wall penetrations, and at any slab junctions. When installing down to an adjacent flat surface such as a garden bed or pathway, a minimum of 150mm from the ground is recommended to prevent rain splash back dirtying the façade.

ITEMS ON THIS PAGE				
CODE	DESCRIPTION	LENGTH	SUPPLIED BY FAIRVIEW	
TRM0503	20 x 70 x 1.6 L-Angle	6.5m	•	

STEP 4 – VERTICAL TRIMS




Install the vertical trims for the cladding, at the left and right of the cladding section, at either side of any wall penetrations, and at any corners.

Note: the cladding system is designed to be installed continuously around the building. Pick a cladding direction (Left-Right or Right-Left) and maintain this direction across the whole project. If the cladding is being completed in sections, it is important the trims for either side of a cladding zone are installed prior to the cladding being installed to ensure a clean finish.

ITEMS ON THIS PAGE

CODE	DESCRIPTION	LENGTH	SUPPLIED BY FAIRVIEW
TRM1101	Shadow Starter Strip	6.5m	•
TRM1403b	Shadow External Shadowline Cover (Female)	6.5m	•
TRM0201b	Stop End (Female)	6.5m	•
TRM1301b	Shadow Internal Shadowline Cover (Female)	6.5m	•
T1550/15	15mm Steel Top Hat	6.5m	•

STEP 4 – VERTICAL TRIMS





Install the cladding by cutting the panels to length, hooking the panel into the previous panel, and affixing to the S Batten. In this diagram the cladding direction chosen is Left-Right.

Due to the rainscreen façade system Stryüm utilizes, a minimum airflow gap of 10mm must be maintained at the top and bottom of the cavity.

Note: there may not be room to install cladding panels around the windows, at internal and external corners and at the end of the cladding zone as per the regular method. These panels will need to be trimmed down the length of the panel and fixed through the face. Use packers as required to bring the face of the panel level with the rest of the façade. These fixing will be concealed with the appropriate cover cap.

ITEMS ON THIS PAGE				
CODE	DESCRIPTION	LENGTH	SUPPLIED BY FAIRVIEW	
SH160	Shadow 160	6.5m	•	
OR				
SH200	Shadow 200	6.5m	•	
OR				
SH300	Shadow 300	6.5m	•	
OR				
SH90/90	Shadow 90/90 (NEW)	6.5m	•	
OR				
SH170/95	Shadow 170/95 (NEW)	6.5m	•	

STEP 6 – CLIP ON COVER PIECES



Install the cover sections to the two-piece trims to conceal rivets and cut edges. Push firmly into place, a rubber mallet may be used paying careful attention to the finish.

ITEMS ON THIS PAGE


CODE	DESCRIPTION	LENGTH	SUPPLIED BY FAIRVIEW
TRM1403a	Shadow External Shadowline Cover (Male)	6.5m	•
TRM0201a	Stop End (Male)	6.5m	•
TRM1301b	Shadow Intern Shadowline Cover (Male)	6.5m	•

8. SHADOW VERTICAL


8.2 GENERAL DETAILS

SHADOW VERTICAL – GENERAL DETAILS


SHADOW V PANEL CONNECTION




SHADOW V PANEL CONNECTION




SHADOW V PANEL END




SHADOW V HEAD SLAB JUNCTION




SHADOW V BASE SLAB JUNCTION




SHADOW V PANEL END FLOOR




SHADOW V WINDOW JAMB




SHADOW V WINDOW HEAD




SHADOW V WINDOW SILL




SHADOW V EXTERNAL CORNER 1




SHADOW V EXTERNAL CORNER 2




SHADOW V EXTERNAL CORNER 3




SHADOW V INTERNAL CORNER 1




SHADOW V INTERNAL CORNER 2





SHADOW V SOFFIT




SHADOW V SOFFIT JUNCTION 1




SHADOW V SOFFIT JUNCTION 2



SHADOW V PARAPET



SHADOW V PANEL CONNECTOR






9. SHADOW HORIZONTAL

9.1 INSTALLATION GUIDE

SHADOW HORIZONTAL – INSTALLATION GUIDE

Please ensure you review the complete Stryüm Shadow Horizontal details on pages 44-60 to ensure you order all the required trims, the following step by step is a guide only.

STEP 1 – WATERPROOF MEMBRANE




As Stryüm is a rainscreen façade, a weathertight membrane must be installed over the supporting wall. This membrane needs to meet the project specific requirements for weathertightness and be installed as per manufacturers guidelines. All penetrations through the membrane must be sealed.

ITEMS ON THIS PAGE			
CODE	DESCRIPTION	LENGTH	SUPPLIED BY FAIRVIEW
N/A	Waterproof Membrane	N/A	•
	Please contact Fairview		

*Proclima Extasana Wall Membrane was used as part of Stryüm AS4384 testing and is recommended for most applications, however project specific requirements need to be considered before selecting the appropriate membrane.

STEP 2 – SUBSTRATE



Packers for a plumb substrate and ventilation need to be installed as required prior to the installation of the Stryüm S Batten.


Install Stryüm S Batten substrate vertically. The substrate needs to be level to ensure the cladding is flat once installed. Any imperfections in this substrate will be highlighted once the panels are installed.

Stryüm S Battens are installed at maximum 600mm centres. Project specific requirements may dictate shorter span lengths.

ITEMS ON THIS PAGE

CODE	DESCRIPTION	LENGTH	SUPPLIED BY FAIRVIEW
TRM0901	35mm Stryüm S Batten	6.5m	•

STEP 3 – VERTICAL TRIMS



Install the vertical trims for the cladding, at the left and right of the cladding section, at either side of any wall penetrations, and at any corners. When installing down to an adjacent flat surface such as a garden bed or pathway, a minimum of 150mm from the ground is recommended to prevent rain splash back dirtying the façade.

If the cladding is being completed in sections, it is important the trims for either side of a cladding zone are installed prior to the cladding being installed to ensure a clean finish.

ITEMS ON THIS PAGE				
CODE	DESCRIPTION	LENGTH	SUPPLIED BY FAIRVIEW	
TRM0503	20 x 70 x 1.6 L-Angle	6.5m	•	
TRM1401	Shadow Box Section	6.5m	•	
TRM1303	Shadow W Section	6.5m	•	


STEP 4 – HORIZONTAL TRIMS



Install the horizontal trims for the cladding, at the top and bottom of the cladding section, above and below any wall penetrations, and at any slab junctions.

ITEMS ON THIS PAGE			
CODE	DESCRIPTION	LENGTH	SUPPLIED BY FAIRVIEW
TRM1101	Shadow Starter Strip	6.5m	•
TRM0201b	Stop End (Female)	6.5m	•
T1550/15	15mm Steel Top Hat	6.5m	•

STEP 5 – INSTALL CLADDING




Install the cladding by cutting the panels to length, hooking the panel into the previous panel, and affixing to the S Batten. Due to the rainscreen façade system Stryüm utilizes, a minimum airflow gap of 10mm must be maintained at the top and bottom of the cavity.

Note: there may not be room to install cladding panels around the windows, and at the top and bottom of the cladding zone as per the regular method. These panels will need to be trimmed down the length of the panel and fixed through the face. Use packers as required to bring the face of the panel level with the rest of the façade. These fixings will be concealed with the appropriate cover cap.

ITEMS ON THIS PAGE			
CODE	DESCRIPTION	LENGTH	SUPPLIED BY FAIRVIEW
SH160	Shadow 160	6.5m	•
	OR		
SH200	Shadow 200	6.5m	•
	OR		
SH300	Shadow 300	6.5m	•
	OR		
SH90/90	Shadow 90/90 (NEW)	6.5m	•
	OR		
SH170/95	Shadow 170/95 (NEW)	6.5m	•

STEP 6 – CLIP ON COVER PIECES



Install the cover sections to the two-piece trims to conceal rivets and cut edges. Push firmly into place, a rubber mallet may be used paying careful attention to the finish.


ITEMS ON THIS PAGE			
CODE	DESCRIPTION	LENGTH	SUPPLIED BY FAIRVIEW
TRM0201a	Stop End (Male)	6.5m	•

9. SHADOW HORIZONTAL


9.2 GENERAL DETAILS

SHADOW HORIZONTAL – GENERAL DETAILS


SHADOW H PANEL CONNECTION




SHADOW H PANEL START END




SHADOW H HEAD SLAB JUNCTION




SHADOW H BASE SLAB JUNCTION




SHADOW H SLAB JUNCTION CONCEALED




SHADOW H PANEL END FLOOR




SHADOW H WINDOW JAMB




SHADOW H WINDOW HEAD




SHADOW H WINDOW SILL




SHADOW H EXTERNAL CORNER 1




SHADOW H EXTERNAL CORNER 2




SHADOW H INTERNAL CORNER




SHADOW H SOFFIT




SHADOW H SOFFIT JUNCTION 1




SHADOW H SOFFIT JUNCTION 2



SHADOW H PARAPET



SHADOW H PANEL CONNECTOR




10. SEAM VERTICAL

10.1 INSTALLATION GUIDE

SEAM VERTICAL – INSTALLATION GUIDE

Please ensure you review the complete Stryüm Seam details on pages 72-88 to ensure you order all the required trims, the following step by step is a guide only.

STEP 1 – WEATHERTIGHT MEMBRANE




As Stryüm is a rainscreen façade, a weathertight membrane must be installed over the supporting wall. This membrane needs to meet the project specific requirements for weathertightness and be installed as per manufacturers guidelines. All penetrations through the membrane must be sealed.


ITEMS ON THIS PAGE			
CODE	DESCRIPTION	LENGTH	SUPPLIED BY FAIRVIEW
N/A	Waterproof Membrane	N/A	•
	Please contact Fairview		

*Proclima Extasana Wall Membrane was used as part of Stryüm AS4384 testing and is recommended for most applications, however project specific requirements need to be considered before selecting the appropriate membrane.

STEP 2 – SUBSTRATE



Use Stryum Perforated S Batten as the top most batten.



*Take note of the S Batten orientation



Packers for a plumb substrate and ventilation need to be installed as required prior to the installation of the Stryum S Batten.


Install Stryum S Batten substrate horizontally. The substrate needs to be level to ensure the cladding is flat once installed. Any imperfections in this substrate will be highlighted once the panels are installed.

Stryum S Battens are installed at maximum 600mm centres. Project specific requirements may dictate shorter span lengths. Use Perforated S Batten as the top batten.

ITEMS ON THIS PAGE

CODE	DESCRIPTION	LENGTH	SUPPLIED BY FAIRVIEW
TRM0901	35mm Stryum S Batten	6.5m	•
TRM0903	35mm Stryum S Batten Perforated	6.5m	•


STEP 3 – HORIZONTAL TRIMS



Install the horizontal trims for the cladding, at the top and bottom of the cladding section, above and below any wall penetrations, and at any slab junctions. When installing down to an adjacent flat surface such as a garden bed or pathway, a minimum of 150mm from the ground is recommended to prevent rain splash back dirtying the façade.

ITEMS ON THIS PAGE			
CODE	DESCRIPTION	LENGTH	SUPPLIED BY FAIRVIEW
TRM4201	Seam Foot Mould	6.5m	•
TRM0506	50 x 50 x 1.6 L-Angle	6.5m	•

STEP 4 – VERTICAL TRIMS




Install the vertical trims for the cladding, at the left and right of the cladding section, at either side of any wall penetrations, and at any corners.

Note: the cladding system is designed to be installed continuously around the building. Pick a cladding direction (Left-Right or Right-Left) and maintain this direction across the whole project. If the cladding is being completed in sections, it is important the trims for either side of a cladding zone are installed prior to the cladding being installed to ensure a clean finish.

ITEMS ON THIS PAGE			
CODE	DESCRIPTION	LENGTH	SUPPLIED BY FAIRVIEW
TRM4201	Seam Foot Mould	6.5m	•
TRM0201b	Stop End (Female)	6.5m	•

STEP 5 – INSTALL CLADDING (TO EXTERNAL CORNER)




Install the cladding by cutting the panels to length, hooking the panel into the previous panel, and affixing to the S Batten. In this diagram the cladding direction chosen is Left-Right. Due to the rainscreen façade system Stryum utilizes, a minimum airflow gap of 10mm must be maintained at the top and bottom of the cavity.

When installing Seam around an external corner, install the cladding up to the corner, and trim the final panel down the length till it is flush with the substrate of the adjoining wall. Insert packers behind the cladding and fix through the face of the panels.

ITEMS ON THIS PAGE				
CODE	DESCRIPTION		LENGTH	SUPPLIED BY FAIRVIEW
SE260	Seam 260		6.5m	•
OR				
SE130/130	Seam 130/130 (NEW)		6.5m	•

STEP 6 – INSTALL EXTERNAL CORNER



Install the external corner, whilst making sure to cover the screws used to face fix the cladding on the adjoining wall.

ITEMS ON THIS PAGE			
CODE	DESCRIPTION	LENGTH	SUPPLIED BY FAIRVIEW
TRM0201b	Stop End (Female)	6.5m	•

STEP 7 – INSTALL CLADDING (TO INTERNAL CORNER)



Install the cladding by cutting the panels to length, hooking into the previous panel, and affixing to the S Batten.

Note: there may not be room to install cladding panels around the windows, at internal and external corners and at the end of the cladding zone as per the regular method. These panels will need to be trimmed down the length of the panel and fixed through the face. Use packers as required to bring the face of the panel level with the rest of the façade. These fixings will be concealed with the appropriate cover cap.

Once the end of the wall is reached, trim the panel to length, insert packers and fix through the face of the cladding. Note, the face fix screws should be installed behind the substrate of the previous façade, as these will be concealed by the start of the new wall of cladding.

ITEMS ON THIS PAGE				
CODE	DESCRIPTION	LENGTH	SUPPLIED BY FAIRVIEW	
SE260	Seam 260	6.5m	•	
OR				
SE130/130	Seam 130/130 (NEW)	6.5m	•	

STEP 8 – INSTALL INTERNAL CORNER



Install TRM0201b Female into the internal corner.

ITEMS ON THIS PAGE			
CODE	DESCRIPTION	LENGTH	SUPPLIED BY FAIRVIEW
TRM0201b	Stop End (Female)	6.5m	•

STEP 9 – INSTALL CLADDING (FROM EXTERNAL CORNER)



Install packers adjacent to TRM0201b and trim the raised hook/starter section from the length of the Seam panel. Install this trimmed first panel up against TRM0201b and fix through the face of the cladding into the packers.

Install as standard along the length of the wall until the end of the wall is reached. To complete the wall, trim the panel to length, insert packers, and fix through the face of the material.

ITEMS ON THIS PAGE			
CODE	DESCRIPTION	LENGTH	SUPPLIED BY FAIRVIEW
SE260	Seam 260	6.5m	•
OR			
SE130/130	Seam 130/130 (NEW)	6.5m	•

STEP 10 – CLIP ON COVER PIECE



Install the cover sections to the two-piece trims to conceal rivets and cut edges. Push firmly into place, a rubber mallet may be used paying careful attention to the finish.

ITEMS ON THIS PAGE			
CODE	DESCRIPTION	LENGTH	SUPPLIED BY FAIRVIEW
TRM0201a	Stop End (Male)	6.5m	•




10. SEAM VERTICAL


10.2 GENERAL DETAILS

SEAM VERTICAL – GENERAL DETAILS


SEAM V PANEL CONNECTION




SEAM V PANEL START




SEAM V PANEL END




SEAM V HEAD SLAB JUNCTION




SEAM V BASE SLAB JUNCTION




SEAM V SLAB JUNCTION CONCEALED




SEAM V PANEL END FLOOR




SEAM V WINDOW JAM




SEAM V WINDOW HEAD




SEAM V WINDOW SILL




SEAM V EXTERNAL CORNER




SEAM V INTERNAL CORNER





SEAM V SOFFIT




SEAM V SOFFIT JUNCTION 1




SEAM V SOFFIT JUNCTION 2



SEAM V PARAPET



SEAM V PANEL CONNECTOR




11. STEP HORIZONTAL

11.1 INSTALLATION GUIDE

STEP HORIZONTAL – INSTALLATION GUIDE

Please ensure you review the complete Stryüm Step details on pages 98-111 to ensure you order all the required trims, the following step by step is a guide only.

STEP 1 – WEATHERTIGHT MEMBRANE




As Stryüm is a rainscreen façade, a weathertight membrane must be installed over the supporting wall. This membrane needs to meet the project specific requirements for weathertightness and be installed as per manufacturers guidelines. All penetrations through the membrane must be sealed.

ITEMS ON THIS PAGE			
CODE	DESCRIPTION	LENGTH	SUPPLIED BY FAIRVIEW
N/A	Waterproof Membrane	N/A	•
	Please contact Fairview		

*Proclima Extasana Wall Membrane was used as part of Stryüm AS4384 testing and is recommended for most applications, however project specific requirements need to be considered before selecting the appropriate membrane.

STEP 2 – SUBSTRATE




Packers for a plumb substrate and ventilation need to be installed as required prior to the installation of the Stryüm S Batten.

Install Stryüm S Batten substrate vertically. The substrate needs to be level to ensure the cladding is flat once installed. Any imperfections in this substrate will be highlighted once the panels are installed.

Stryüm S Battens are installed at maximum 600mm centres. Project specific requirements may dictate shorter span lengths.

ITEMS ON THIS PAGE			
CODE	DESCRIPTION	LENGTH	SUPPLIED BY FAIRVIEW
TRM0901	35mm Stryüm S Batten	6.5m	•


STEP 3 – VERTICAL TRIMS



Install the vertical trims for the cladding, at the left and right of the cladding section, at either side of any wall penetrations, and at any corners. When installing down to an adjacent flat surface such as a garden bed or pathway, a minimum of 150mm from the ground is recommended to prevent rain splash back dirtying the façade. If the cladding is being completed in sections, it is important the trims for either side of a cladding zone are installed prior to the cladding being installed to ensure a clean finish.

ITEMS ON THIS PAGE				
CODE	DESCRIPTION	LENGTH	SUPPLIED BY FAIRVIEW	
TRM0508	20 x 70 x 1.6 L-Angle	6.5m	•	
TRM5401	Step X Section	6.5m	•	
TRM5401	Step W Section	6.5m	•	


STEP 4 – HORIZONTAL TRIMS



Install the horizontal trims for the cladding, at the top and bottom of the cladding section, above and below any wall penetrations, and at any slab junctions.

ITEMS ON THIS PAGE			
CODE	DESCRIPTION	LENGTH	SUPPLIED BY FAIRVIEW
TRM5101	Step Starter Strip	6.5m	•
TRM0201b	Stop End (Female)	6.5m	•


STEP 5 – INSTALL CLADDING



Install the cladding by cutting the panels to length, hooking the panel into the previous panel, and affixing to the S Batten. Due to the rainscreen façade system Stryüm utilizes, a minimum airflow gap of 10mm must be maintained at the top and bottom of the cavity.

ITEMS ON THIS PAGE			
CODE	DESCRIPTION	LENGTH	SUPPLIED BY FAIRVIEW
ST250	Step	6.5m	•


STEP 6 – PACKER FOR WALL PENETRATION



Due to the sloping nature of Step, the depth packer required to support the panel around wall penetrations will depend on where the penetrations sit down the panel. Measure carefully where the panel needs to be cut, and calculate the packer required before.


This step will need to be repeated for any wall penetration, including the window head, and the top of any wall sections including slab junction, parapet and soffit details.

STEP 7 - INSTALL CLADDING



ITEMS ON THIS PAGE			
CODE	DESCRIPTION	LENGTH	SUPPLIED BY FAIRVIEW
ST250	Step	6.5m	•

STEP 8 - CLIP ON COVER PIECE



Install the cover sections to the two-piece trims to conceal rivets and cut edges. Push firmly into place, a rubber mallet may be used paying careful attention to the finish.


ITEMS ON THIS PAGE			
CODE	DESCRIPTION	LENGTH	SUPPLIED BY FAIRVIEW
TRM0201a	Stop End (Male)	6.5m	•

11. STEP HORIZONTAL


11.2 GENERAL DETAILS

STEP HORIZONTAL – GENERAL DETAILS


STEP H PANEL CONNECTION




STEP H PANEL START END




STEP H SLAB JUNCTION




STEP H BASE SLAB JUNCTION




STEP H SLAB JUNCTION CONCEALED




STEP H PANEL END FLOOR




STEP H WINDOW JAM




STEP H WINDOW HEAD




STEP H WINDOW SILL




STEP H EXTERNAL CORNER




STEP H INTERNAL CORNER




STEP H SOFFIT



STEP H PARAPET




STEP H PANEL CONNECTOR



12. FABRICATION DETAIL

12.1 FABRICATION CONSIDERATIONS




SCREWING

Stryüm can be screwed with conventional stainless steel or class 3 self-drilling screws for metal. Wind loading calculations in this manual are based on a 12-gauge Tek Screw.



RIVETING

Riveting is possible with the usual equipment and solid rivets or blind rivets.



DRILLING

Stryüm can be drilled with centre point twist drills normally used for aluminium or steel. Use High-Speed Steel (HSS) drill bits.

13. WARRANTY

Stryüm is an incredibly durable material when used in the right application. Please contact your Fairview representative for full terms and conditions.

13.1 IMPORTANT WARRANTY INFORMATION

Maintaining your Stryüm finish is an important component to upholding your warranty. Cleaning frequencies are based on your project location and provided in the warranty; therefore, you should document each time your Stryüm panels are cleaned.

Recommended cleaning agents:

- Mineral Spirits
- Organic Cleaners
- PH-Neutral Solvents

14. MISCELLANEOUS

14.1 MANUFACTURING QUALITY

A dedication to the total fulfilment of our client's and customer's expectations is reflected by a complete quality control system, beginning at the point of specification and continuing through to delivery of the guaranteed products. All activities are carried out in a manner which:

- Uses the framework of ISO9001 Quality Standard to verify the quality of our systems
- Ensures that our products and services are of the highest standards
- Creates continuous improvements to our product through the application of the best quality practices.

ACCEPTABLE VARIATION

WIDTH	± 2.4mm
LENGTH	± 6.0mm
THICKNESS	±.4mm (maximum)
SURFACE DEFECTS	The surface shall not have any irregularities such as dents, scratches and other imperfections in accordance with our quality assurance.

MATERIAL DATA

ALUMINIUM ALLOY	6060, 6063
GRADE	T5

HANDLING AND STORAGE

- Considerable care should be taken in the handling of Stryüm
- A minimum of two people should be used when moving large sheets to avoid scratching
- To prevent surface damage when stacking Stryüm, there should be no swarf between the panels, and a cover sheet of paper or foam sheet should be used
- Stryüm should be stored in a cool and dry area where temperature is relatively stable
- If exposed to heat (direct sunlight etc.) and humidity, in its plastic packaging, Tiger Stripping may develop, negatively impacting the appearance of the panels. Tiger Stripping occurs when moisture is absorbed into the powder coating. Should this occur, the coating will dry over time and the Tiger Stripping should disappear
- Pallets of Stryüm should be stored horizontally with adequate support to prevent sagging

SUSTAINABILITY

Stryüm has been designed with an expected performance life of over 50 years. All Fairview products have been developed with the health of environment and community in mind. As part of our commitment to using recyclable or reusable materials wherever possible, all Stryüm panels are 100% recyclable.

14.2 REPORT REGISTER

BCA 2019 VOL1 SECTION:	DESCRIPTION	TEST/ASSESSMENT	REPORT/REFERENCE NUMBER
C – Fire resistance	Combustibility (Powder Coat)	AS 1530.1*	FNC11437A
	Combustibility (Anodised)	AS1530.1*	FNC11417A
	Early Fire Hazard Properties	AS 1530.3	FNE12443
B - Structural	Large Body Impact	AS1170.2	2016-020-S4-S6
	Cyclonic testing	AS4040.3	2016-020-S7
F – Health and Amenity	Weatherproofing	AS4284	2018-100-S2
G – Ancillary provisions	BAL Ratings	IGNIS Assessment	IGNS-5200 ISSUE 02
Additional/Supporting	Coating Standard	AAMA2604	36048

*AS1530.1 testing for Woodgrain Finish to be completed





FAIRVIEW™

DEFINING ARCHITECTURE SINCE 1988



AUSTRALIA
NEW ZEALAND
UNITED KINGDOM

SALES ENQUIRIES 1800 007 175

HELPDESK@FV.COM.AU

FV.COM.AU

STRYUM / NOVEMBER 2022